



Installing a Dump valve to a Smart car



Forge dump valve kit as supplied



Loosen the clamps securing the intercooler pipe



Remove the pipe



New Forge hose completely replaces stock hoses




Fit valve and vacuum hose supplied



Fix "T" to Vacuum Hose



Insert "T" into vacuum line that leads to the fuel regulator



With the Valve installed tighten all clamps and secure the vacuum hose with the tie wraps supplied.



After checking that all tools have been removed replace the engine cover

ENGINEERED FOR PERFORMANCE