



VW T5.2 Oil Cooler Instructions



Tools Required:

Oil filter removing tool

Adjustable spanners

10mm socket and ratchet

10mm spanner

1" socket, long extension and ratchet

1. Having installed your forge motorsport intercooler before replacing the bumper, drain oil and remove oil filter. Bolt on the oil cooler with brackets, nuts, washers and bolts supplied in the kit.



2. Assemble the oil take off plate with the NA dash fittings angled in together but with a small gap between and tighten. Place spacer and O ring on the bottom and threaded extension through the middle.



3. Place the spacer plate assembly where the oil filter screws on, Tighten in position shown below making sure there is clearance all around and then replace oil filter.



4. Feed the braided hoses through the radiator pack as shown below screw on the NA dash fittings and tighten. Please refer back to the intercooler instructions to replace bumper.



Engineered for performance.

